

# Rules & requirements, design of equipment

ANSI Standard Z358.1 2014 & SS-EN15154-1 & 2:2006

## IMPORTANT!

- Material in the shower should be adapted to the environment where it is placed
- The performance of the shower should be adapted to its potential users
- Showers should be in the immediate vicinity, and be reachable within a few seconds
- Tempered water should always be considered
- After activation of water will come after 1 second
- The valves must not be self-closing
- Protection should be of nozzles on eye-/facial showers
- Pressure and flow-regulated water is a major advantage
- All emergency showers should be well aware of clear sign
- Functional Test equipment regularly, and document
- A safety mixer that is adapted for your purpose should be installed
- The water should be of good quality
- Install noise/flashing alarm of showers that are located alone

